

HOME[®] SECURE 868MHz

Fjärrkontroll



Introduktion

1

- 1 Aktivera larmsystem: Sätter larmsystemet i Aktiverad status.
- 2 Inaktiver larmsystem: Sätter larmsystemet i Inaktiverad status.
- 3 Skalsäkring: Alla sensorer med skalsäkringstypen [Aktiv Zone] slås från, medan sensorer med [Skalsäkring] är aktiverade.
- 4 Panikknapp: Utlöser larmsystemet direkt oavsett tillstånd.

Registrera Fjärrkontrollen

2

Registrering av fjärrkontrollen går till på samma vis som sensorerna.

Efter punkt 6 tryck på fjärrkontrollens panikknapp (🔊) inom 60sek och larmsystemet registrerar fjärrkontrollen automatiskt. Spara genom att trycka på [#] till sist. Det är också möjligt att radera fjärrkontrollen: Välj 2. Clear Keyfob i punkt 4.

- 1 Menu
3. Code Set
4. Zone Bypass
5. Phone Set
6. Event Log
7. Service
8. Programming
- 2 8. Programming
1. Device
2. Comm.
3. System Option
4. Initialization
- 3 1. Device
1. Zone
2. Keyfobs
3. Siren
4. WL. Superv.
- 4 2. Keyfobs
1. Keyfob Register
2. Clear Keyfob
- 5 1. Keyfob Register
1. By Code Learn
2. By Code Input
- 6 1. By Code Learn
1. Keyfob 1
2. Keyfob 2
3. Keyfob 3
- 7 1. Keyfob 1
60 s
- 8 1. Keyfob 1
Registered!
WL. ID is:
Save ID?